

## Camera Capture



	ezcap331	ezcap322C	ezcap335	ezcap313	ezcap314	
<b>1080P60 CAPTURE</b>	√	√	√	√	√	
<b>2160P30 CAPTURE</b>	√	√	√	×	×	
<b>INPUT CHANNELS</b>	1	1	4	1	2	
<b>INTERFACE</b>	USB3.0	USB3.1 Type-C	PCIe X4	USB2.0	USB Type-C	
<b>VIDEO OUTPUT FORMAT</b>	YUY2, NV12, RGB	YUY2, NV12, RGB	YUY2, NV12, RGB	MJPEG	MJPEG	
<b>MULTI APP SUPPORT</b>	√	√	√	√	√	
<b>REMARK</b>						

## HD Capture Pro



	ezcap328	ezcap264	ezcap327	ezcap325	ezcap262	
<b>1080P60 CAPTURE</b>	√	√	√	√	√	
<b>1080P60 PASSTHROUGH</b>	√	√	√	×	√	
<b>2160P30 CAPTURE</b>	×	×	only HDMI	only HDMI	×	
<b>2160P30 PASSTHROUGH</b>	×	×	only HDMI	×	×	
<b>VIDEO INPUT</b>	HDMI x4	HDMI x4	SDI/HDMI	SDI/HDMI	SDI	
<b>VIDEO OUTPUT</b>	HDMI	HDMI	HDMI	×	SDI	
<b>INTERFACE</b>	USB3.1 Type-C	USB3.0	USB3.1 Type-C	PCIe x1	USB3.0	
<b>MULTI APP SUPPORT</b>	√	√	√	√	√	
<b>MICROPHONE INPUT</b>	√	√	×	×	×	
<b>LINE INPUT</b>	√	×	×	×	×	
<b>LINE OUTPUT</b>	√	×	×	×	×	
<b>VOLUME CONTROL</b>	√	×	×	×	×	
<b>REMARK</b>	4 channels live switch	4 channels live switch				

## Analog Video Capture



	<b>ezcap159</b>	<b>ezcap158</b>	<b>ezcap172</b>			
<b>INTERFACE</b>	USB2.0	USB2.0 UVC	USB2.0			
<b>SUPPORT SYSTEM</b>	Windows, Mac	Windows, Mac	Windows			
<b>VIDEO INPUT</b>	Composite, S-Video	Composite, S-Video	Composite, S-Video			
<b>NEED DRIVER INSTALLATION</b>	√	×	√			
<b>APPLICATION SOFTWARE</b>	VHStoDVD 5	VHStoDVD 3	ShowBiz 3.5			
<b>SUPPORT TV SYSTEM</b>	PAL/NTSC/SECAM	PAL/NTSC/SECAM	PAL/NTSC/SECAM			
<b>CAPTURE RESOLUTION</b>	NTSC: 720 x480, PAL: 720 x 576	NTSC: 720 x480, PAL: 720 x 576	NTSC: 720 x480, PAL: 720 x 576			
<b>BUTTON SNAPSHOT</b>	√	√	√			
<b>REMARK</b>						